


Cylinder Head

1



Cylinder Head Screw

2




Spark Plug

3



Engine Sump

4



Dipstick

5



Oil Seal

6



Crankcase Gasket

7




Sump Screw

8



Valve

9




Piston Pin

10




Cylinder Head Gasket

11



Compression Ring

12



Oil Ring

13



Piston

14



Connecting Rod

15



Connecting Rod Cap

16




Connecting Rod Screw

17



Crankshaft

18



Breather Tube

19



Intake Manifold

20



Oil Slinger

21



Camshaft

22




Valve Tappet

23



Cylinder Assembly

24




Oil Drain Plug

25



Magneto Armature

26



Blower Housing

27



Flywheel

28



Pulley/Spring Assembly Spring 29



Rotating Screen

30



Rope Starter and Grip

31



Governor Blade

32



Valve Retainer

33



Valve Spring

34




Breather Assembly

35




Breather Gasket

36



Carburetor

37




Intake Manifold O Ring Seal 38



Brake and Stop Switch

39



Control Bracket

40



Muffler

41



Carburetor Diaphragm

42



Air Cleaner Foam Filter 43



Air Cleaner

44



Governor Spring

45



Air Vane Link

46




Fuel Tank Cap

47




Fuel Tank

48



Throttle Shaft and Valve 49



Flywheel Key

50



Grommet

51



Timing Gear

52

